

INSTRUCTIONS

1. Remove at least 3cm (1.25 in) of cable jacket; Untwist and straighten wires



2. Position wires to T568A or T568B configuration. (Trim wire ends if necessary)

CONFIG.	1	2	3	4	5	6	7	8
T568A	W/G	G	W/O	BL	W/BL	O	W/BR	BR
T568B	W/O	O	W/G	BL	W/BL	G	W/BR	BR



3. Insert the wires through Cat6 FastPlug RJ45 in the correct order



4. Terminate with plug with FastPlug Ratchet Crimp Tool (*TEL-6002 Required, Sold Separately*)

1-Step Crimp: All wires are contacted simultaneously and the excess cable ends are cut off!



P/N: NMP-8755-100J

FASTPLUG
RJ45